


MOUNTING INSTRUCTION ALU-RAMPS BT4000


UK	I Fitting Instructions
SE	I Monteringsanvisning
DK	I Monteringsvejledning
DE	I Montageanleitung
FR	I Instruction de montage
PL	I Instrukcja montazu
NO	I Installasjonsanvisninger
IT	I Istruzioni per il montaggio




2025-03-31

Brenderup Group


Components




12x




2x




2x



2x




2x




2x

1

BT4310



2




New Item No:


Brenderup Group

3


BT4260






4



Lock in transport mode



Lock when in use

**Caution!****Varning!****Warnung!****Advarsel!****Avertissement!****Ostrzeżenie!****Advarsel!****Avvertimento!**

The lock must be mounted when using the ramp

Låsningen måste monteras vid användning av rampen

Bei Benutzung der Rampe muss das Schloss montiert sein

Låsen skal monteres ved brug af rampen

Le verrou doit être installé lors de l'utilisation de la rampe

Podczas korzystania z rampy należy zamontować zamek

Låsen skal monteres ved bruk av rampen

La serratura deve essere montata quando si utilizza la rampa

Copyright © 2018 Brenderup Group. All rights reserved. We reserve the right to change design details, specifications and equipment levels without prior notice. Reservations for errors in technical specifications, information and images.